



### 曲轴箱 (Crankcase)

序号 No.	零部件图号 Part No.	零部件名称	Description	规格状态	数量 (Reqd. QTY)	易损属性 CONSUMABLE GRADE
1	380140215-0003	六角头法兰面螺栓	Hexagon bolt with flange	GB/T 16674.1_M6	2	C
2	281850152-0001	油位传感器	Oil level sensor	T110_电感式;	1	B
3	380630099-0001	轴承	Bearing	GB/T 276_6202;	1	B
4	380450522-0001	平垫圈	Flat washer	T110_T21_内径8	1	C
5	381350004-0001	销夹	Pin clip	T040_调速臂用;	1	A
6	171630003-0001	调速臂	Speed regulating arm	T110;	1	B
7	380650339-0001	油封	Oil seal	T110_d=8_D=14_	1	B
8	110260024-0001	密封螺塞	Sealing plug screw	T110_M12x1.5x1	1	C
9	380450516-0001	平垫圈	Flat washer	T110_T21_内径12	2	C
10	110810028-0001	曲轴箱体	Crankcase body	T120_有孔;含Hg/	1	B
11	380940346-0001	定位线卡	Location wire nail	T560;	1	A
12	380140001-0006	六角头法兰面螺栓	Hexagon bolt with flange	GB/T 16674.1_M6	1	B