

General Spares List



Wallis Close, Park Farm South  
 Wellingborough, Northamptonshire  
 NN8 6AG United Kingdom  
 Tel: +44 (0) 1933 677911  
 Fax: +44 (0) 1933 677916  
[info@stephill-generators.co.uk](mailto:info@stephill-generators.co.uk)  
[www.stephill-generators.co.uk](http://www.stephill-generators.co.uk)

SSD10000S	
<b>Engine</b>	Kubota D722-E4B (EU Stage V)
<b>Alternator</b>	NSM C112 SB
<b>Prime Power (PRP)</b>	10.0 kVA / 8.0 kW
<b>Fuel tank capacity</b>	37.0 Litres
<b>Oil Type</b>	15W-40



\* All canopy metalwork parts can be identified using the exploded view found in the SSD10000S handbook available from:  
[www.stephill-generators.co.uk](http://www.stephill-generators.co.uk)

Description	Part No.	Qty
Oil filter	015-0004	1
Fuel Filter	015-0005	1
In-line Fuel Filter	015-0030	1
Air Filter	015-0003	1
Fan Belt	015-0007	1
Engine Kubota D722-E4B	015-0054	1
Charge Regulator Kubota D722	015-0078	1
Oil Pressure Switch Kubota D722	015-1003	1
Temperature Switch Kubota D722	015-0008	1
Fuel Pump 12V Kubota	015-0125	1
Fuel Stop Timer Relay Kubota	015-0018	1
Alternator NSM C112 SB	028-0048	1
55µF Capacitor (to fit the above)	037-0023	1
Silencer SSD10000S	024-0108	1
Manifold Pipe SSD10000S	024-0110	1
Down Pipe SSD10000S	024-0111	1
Fuel Tank SSD10000S	024-0129	1
Fuel Cap (Lockable) c/w Keys	048-1004	1
Fuel Drain Hose Kit	024-1004	1
Fuel Sender	024-1006	1
Air Intake Hose (0.5M)	024-1007	1
Oil Drain Hose Kit	024-1005	1
Door Lock - Black Paddle	024-1001	2
Door Hinge M5	014-1000	4
Door Seal (rubber edging) 2M	023-1023	2
Door - Control Panel (complete)	024-1031	1
Mounts - Engine & Alternator	027-0016	4
12V Battery MJ40R 055	054-0003	1
Battery Terminal - Positive	038-0107	1
Battery Terminal - Negative	038-0108	1
Battery Terminal Sleeves (set)	054-0005	1
Battery Terminal Cover - Red	038-0105	1
Battery Terminal Cover - Black	038-0106	1

Description	Part No.	Qty
<b>Control Panel 115/230V</b>		
Reset Button 16A	036-0049	2
Reset Button 30A	036-0052	3
Reset Button 20A	036-0050	1
Reset Button 2A	036-0055	2
IP23 Cover -Resets	036-0056	6
40A Double Pole MCB	036-0018	1
40A Double Pole RCD 30mA	036-0028	1
Socket-115V 32A	044-0003	2
Socket-115V 16A	044-0001	1
Socket-230V 16A	044-0002	1
Socket-230V 32A	044-0004	1
Voltage Selector Switch	043-0007	1
MCB Cover (4 module)	036-0039	1
Relay-4pin 12V DC	056-0002	3
Relay-4pin 12V DC 70A	056-0003	1
Fuel Gauge	055-0010	1
Emergency Stop Button - N/C	045-0018	1
Contact Block (only) - N/C (for the above)	045-0032	1
Fuel Pump Prime Button	045-0006	1
Deep Sea 3110 Control Module	045-0061	1
3110 Rubber Gasket (for the above)	045-0062	1
Bridge Rectifier 25A	045-0026	1
DC Engine Loom	039-0007	1
DC Control Panel Loom	039-0008	1

<b>Trolley Kit</b>		
Axle	024-0130	1
Trolley Handle	024-0132	2
Trolley Frame	024-0133	1
Roll Pin	024-1019	2
Compression Spring	024-1020	2
Wheel - Pneumatic	027-0020	2

For enquires of other parts not shown contact:  
[info@stephill-generators.co.uk](mailto:info@stephill-generators.co.uk) Tel: +44 (0) 1933 677911